


CAUTION! Make sure machine is unplugged from electrical current. For a correct cleaning process please follow the instructions bellow.



1. Take off the front cover.



2. Take out the filters.



3. Take out the peel guides.



4. Take off the juice tank.



5. Extract the knife by pulling it towards you.
CAUTION! The blade is very sharp, be careful not to cut yourself.



6. Pull off the peel ejectors.



7. Unscrew the securing knobs of the pressing units.



8. Take off the pressing units in pairs.



9. Remove the chute of the podium.



10. Empty peel bin.

INFORMATION: All pieces, **EXCEPT THE FRONT COVER**, can be cleaned in a dishwasher.
The juice extraction zone and the front cover should be cleaned using a moist cloth and dish washing liquid.
Rinse with clean water to remove any washing liquid traces.



11. Replace the dismantled pieces with clean ones.



12. Mount the chute.



13. Mount the pressing units by pairs.



14. Fix the knobs and tighten them well. Missing knobs are to be replaced immediately. Never operate the machine with any knob missing.



15. Put on the peel ejectors. Push them firmly to assure their right positioning in order to avoid breakage while using the machine.



16. Put on the knife. Push until it clicks into place with a "click".



17. Mount the juice tank.



18. Mount the peel guides.



19. Insert both juice filters.



20. Put the plastic cover.