


# RANNIO

## PROFESSIONAL HEAT LAMP

Instruction Manual



### HEAT LAMP

# RANNIO HTL-01/02

HEAT LAMP

#### Specifications

**Mounting Type:**

Ceiling Mount

**Voltage:**

220-240V/ 50 - 60Hz

The installation by professional technician or certificated electrician is highly recommended.

#### Installation step:

**Step 1.** Install "S" hook on a stable and heavy-loaded resistible ceiling surface. Connect power cord accordingly. The HEAT LAMP must be grounded.


**Step 2.** Hang "S" hook on the top of "stretchable cable cord" properly.

**Step 3.** Lift the Lamp Black Base Cover to the top.

**Step 4.** Hold the top of metal lamp then stretch in a suitable length (300~1100mm).

**Step 5.** Screw the E27 infrared bulb in by clockwise.

Bulb is not include in the package.



Step



Step

Step

Step

Step

KARMA GLOBAL LTD. 14F-7, NO.77, SHI CHEN NORTH 1 RD., TAICHUNG, TAIWAN  
TEL: +886(0)4 22 58 99 81 FAX: +886(0)4 22 58 02 65 [www.rannio.com](http://www.rannio.com)